



INSTALLATION AND MAINTENANCE PT01 & PT02 Picnic Tables

INSTALLATION

- All tables and seating should be mounted level to the ground. Packing may be required due to inconsistencies in the concrete slab.
- 10mm Dyna bolts or chemsets are used for securing all tables.



Timber Battens

- Regular inspections of the timber should be carried out every 3 – 6 months to check for any damage or wear and tear to the finished surface.
- We recommend washing the timber down with water and detergent. Any damage to the timber or break in the protective clear coat will need to be repaired.
- The timber should be gently sanded back and a new clear coat applied. If necessary, the area may need freshening up with a coat of natural stain prior to clear coating.
- This method can be used to repair just a small area or to repair the entire length of the batten if necessary.
- We recommend light sanding and re staining should occur annually to maintain the look of your seat.
- We use Intergrain Natural Stain New Merbau Kwila and Feast and Watsons Marine Grade all weather proof clear coat.



Powder Coat Care

- Powder coated seat components that become dull due to prolonged exposure to direct sunlight can be restored with an appropriate surface polish.
- Regular washing down of the powder coated surface will help prolong the lustre of the powder coated finish.
- Do not use any solvents on the surface as this will adversely affect the longevity of the powder coated finish.
- Surface scratches and inconsistencies can be touched up using Dulux touch up paint. Most colours can be matched.



Bolts

- Mounting bolts should be checked monthly to ensure they are secure.
- We recommend using loctite to help secure the nuts in place.

Spare parts

All seat components are available individually from our service department. We offer a full parts and technical back up service of all our products.

